

# Find Root Cause Immediately

### HS35iQ Encoder with PulselQ<sup>™</sup> Technology

Providing visual indication of encoder health through fault specific LEDs and digital output.



# Frustrated With Downtime And The Lack Of Ability To Find Root Cause?

The **HS35iQ Encoder with PulselQ™ Technology** transforms the troubleshooting workflow by providing specific fault indication, allowing you to rule out the encoder or correct the root cause before unexpected downtime occurs.

### SPECIFIC FAULT INDICATION

**See exactly what is at fault so you can find root cause with confidence**. No more guessing or replacing only to have the problem occur again. Fault notification provided via on-board LEDs or dedicated fault output, which can be connected to PLC or other controlling device.



### Insufficient Voltage

Sense supply voltage changes and low voltage conditions that are otherwise difficult to detect.



#### Overspeed

Detect shaft speed exceeding predetermined limit.



### **Cable Integrity**

For 7272 differential line driver options, catch encoder cable 'open' faults such as cable breaks, shorts, or loose connectors.

YL
-57
V

#### **Electronic Failure**

Continuously monitor electronics which may result in irregular pulse output.



### **Coupling Slip**

Detect clamping collar slip, between the shaft and encoder physical connection, prior to coupling failure. (Patent #US11353343B2)



#### Over/Under-Temperature

Measure internal encoder temperature to provide early indication of operating condition changes.

DIAGN

# Need To Keep Spare Units While Reducing Inventory Costs?

Customize encoder specifications to meet your needs with PulselQ<sup>™</sup> Technology. **Simplify and consolidate inventory** by stocking fewer encoder part numbers with programmable output.

### PROGRAMMABLE ENCODER OUTPUT


**Optional programmability of encoder output** characteristics possible via PulselQ<sup>™</sup> Technology Encoder Software. **This enables users to consolidate inventory** by stocking multiple configurations with a single part number and allows for substitution when needed.

Pulses Per Revolution (PPR)	Phasing (from clamp end)
1024	
Z-Polanty Z Standard High (Default)	B 2 -2 -2 -2 -2 -2 -2 -2 -2 -2
7-Index Length	ABZ Signal Voltage
ABZ 1 0 1 2 3 4 POS Z 1 0 1 2 3 4 T80 Electrical Degrees (Default)	
2 Gating	Fault Signal Voltage (REV-D)
A B Z at B is Low (Default)	F HTL.
WARNING Changing the device config Please refer to the software	uration may impact the performance of your system. manual for more details.
CANCEL SET HOME	E POSITION SEND TO DEVICE

### **Programming Options**

- Pulses Per Revolution: Up to 20,000 PPR
- Phase: A leads B Clockwise or Counter-Clockwise
- Signal Output Voltage: Set to TTL or HTL
- Z Index Pulse Polarity: Standard High or Inverted Low
- Z Index Pulse Position and Gating: Set desired home position and gating
- Fault Signal Voltage: Set to TTL or HTL

# Wasted Resources & Time Associated With Guesswork




### PROBLEMS WITH THE CURRENT ENCODER TROUBLESHOOTING WORKFLOW:

- Encoder output is difficult to visualize and tough to effectively trouble-shoot without additional test equipment.
- Lack of visual indication that fault has been resolved until the machine is running.
- No way to catch temporary faults, troubleshoot momentary hiccups, indicative of larger problems.
- Adjustments can often temporarily fix the issue but not the root cause, leading to repeat failures.

# Updated Troubleshooting Workflow With Specific Fault Output

### REVOLUTIONIZE TROUBLESHOOTING WITH IMMEDIATE ROOT CAUSE DATA

- See exactly what is at fault so you can find root cause with confidence.
- No more guessing or wasting time trying to determine the root cause of a problem only to have the problem occur again.
- Quickly review fault conditions and diagnostic data without wasting time.



### **NEW WORKFLOW**

- Fault output sends data to PLC, if connected.
- Use 4 LEDs to find specific fault area to troubleshoot.
- Probable root cause identified in minutes, without guesswork.
- Maintenance identifies detailed corrective actions by connecting to PulselQ<sup>™</sup> Software Tool.





### WHAT OUR CUSTOMERS ARE SAYING

The encoder isn't always the problem, but we need to check it almost every time.

**ELECTRICAL ENGINEER** Steel Industry Customer The troubleshooting capabilities free us to work on more complex issues and stop wasting time root causing simple faults.

APPLICATION MANAGER Machine OEM Customer

# See Encoder Health At A Glance

See exactly what is at fault so you can troubleshoot with confidence. No more guesswork or needless replacement of the encoder.

> Embedded microprocessor evaluates pulses and aggregates running conditions.

LED status lights provide visual indication of potential faults.

Dedicated secondary connector for diagnostic data output and device configuration input.

Onboard memory stores life cycle data and recent fault status.

Rugged design withstands up to 400g shock, 20g vibration. Optional enclosure rating IP67, extended operating temp range available 0°C to +100°C. Imperial and Metric bore sizes up to 1-1/4" or 30mm.

Primary connector provides standard incremental encoder output to drive, optional programmable resolution up to 20,000 PPR.

#### **LED Status Indicators**

White	Green	Red	Blue (Fault Recovery)	Orange (Warning)
LED pulses white when fault	LED pulses green during	LED "flickers* (rapidly flashes) blue for 30 minutes after fault is	LED pulses orange for temperature warning	
is disabled	normal operation	fault condition	corrected or cleared. Event logged in onboard memory.	LED pulses orange for encoder health warning

# Dive Deeper With PulselQ™ Encoder Software Tool

Our intuitive PulseIQ<sup>™</sup> Encoder Software Tool allows users to configure various aspects of the HS35iQ Encoder. Download the software from our website and connected to a PC via USB cable.

Device Jule   Fault Mont	taring   Event Log   Device	Configuration   Mecultaneous	Web Assources		
Model Number	HISTOPROGRAMMENT	Late Operation Time Pressed	29193647		
Swightenbor	12343675-0011	TatalRevolutions			
Date Code (WWYY)	81622	BostCounter	10		
General Generation		No of Decronic Faults	5	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
Fernance Characteristics	51519/00/04	No. of Temperature Faults			
Formana Ruist Tone	5 15 19 (MUEN)	No. of Cable Faulty			
Firmeare Checksum	(C907)	No ofCouping/Overspeed Faults	2		
Series Data		Protein Data		10.00	
Current Pun Time (Since Reboth	0001117	Pulse Court	130		
Current Temperature	-245107-76117	Position Status	CK		
Current Volkege	-1019V	Circular Speed (\$1755)	-0.00		
Ontrois Fast Mediate		Coupling / Overgreed Fault Mentant			
\$		[ee]		BELAY	
Calle Faul Reviewy		Imposion Faid Reducing			
$\prec$		18	×	970 FLC	
	OLEA	R ALL FAILTS			
Aduations				ODYNAPAR	
19.13.11.713 Committing device 19.13.11.713 Device contented	recorded			DTRAPAR	
				EXIT	

#### 1. Device Info

See a general snapshot of the encoder including model number, operating time and number of rotations. View encoder fault status at a glance and quickly review for potential issues.

### 2. Fault Monitoring

Configure specific fault conditions such as temperature limits and overspeed thresholds. View more detailed information on which condition triggered a fault notification and clear faults once reviewed.



Operator New MeeTur Carel Operator Consider After   C 0.000 1 AVX1 Total After Consider After   C 0.000 1 AVX1 Total After Decider Consider After   C 0.000 1 AVX1 Decider After Decider After   C 0.000 1 AVX1 Decider After Decider After   C 0.000 1 AVX1 Decider After Decider After   D 0.000 1 AVX1 Decider After Decider After	
EXCERNING IN LANDING PART INVESTIGATION PROVIDED PROVIDA PROVIDED PROVIDED PROVIDED PROVIDED PROV	
a areas 1 percenter transport percentered	
8 0000 1 NORTH 007000 100 100 100 100	
	BIANY Include
	VF0 PEC
a anno a prot calificative cave cave part December and strong	
OLEAR EVENT LOG	
Meading	ODYNAPAR

### 3. Event Log

View detailed information on the event that triggered a fault, the timestamp, and see recommended corrective actions. The event log saves historical data up to 128 entries with specific fault history.

### 4. Device Configuration

For optional programmable HS35iQ Encoder units only, select desired encoder output options such as resolution, index pulse characteristics, signal voltage and more.

	DISCONNECT DEVICE
Answer has a first financiary and the second	Annala (Annala
CONFIGURE DEVICE	90 PLC
Addution (6.3.3.1.745 (construing during, recorded, (6.3.3.1.745) (construing during, recorded,	ÓDYNAPAF

	DISCONNECT DEVICE	
Device Info   Fault Manitaring   Event Log   Device Configuration Minordianeous   Web Resources		
RECEIVE CONFIGURATION FROM DEVICE		
SEND CONFIGURATION TO DEVICE		
REBOOT DEWOL		
CREATE REPORT		
RESET TO FACTORY SETTINGS		
UPDATE FRAMMARE	MART STORE	
	970 HLC	
Addication 19.33 (3.14) Execution devices	ODYNAPAR	
THE LA LA. THE WORLD BUILDING	EXT	

#### 5. Miscellaneous

Save and load device configuration files to quickly program or set fault conditions. Quickly reboot and/or reset your encoder back to factory default settings. Generate a detailed report of all fault history.

# View Our Helpful Videos And Resources Online

Visit us online for a comprehensive video library explaining the features of the HS35iQ Encoder and how to get started with the PulselQ<sup>™</sup> Technology Software Tool. Our video library includes videos topics such as:

- How to program encoder output
- How to customize fault condition
- How to save and load pre-configured settings
- And many more!







Dynapar Corporation 2100 West Broad Street, Elizabethtown, NC 28337 Phone: 1-800-873-8731 Local: 910-879-5800

#### www.dynapar.com/HS35iQ

© 2023 Dynapar Corporation PulselQ™ is a trademark of Dynapar. 703424-0001 Rev. B